




SMA Backup for STP Hybrid X









BU-STPH-3P63K / BU-STPH-4P63K






BU-STPH-3P63K














BU-STPH-4P63K






BU-STPH-3P63K



BU-STPH-4P63K






BU-STPH-3P63K



BU-STPH-3P63K



SPS IN / SPS OUT






BU-STPH-4P63K



GRID / BACKUP







BU-STPH-4P63K

SPS IN / SPS OUT







1




2



3




4




<https://go.sma.de/service>

5



6

WiFi / LAN



7

Configure Backup

